

NEW!

iDuctor[®]

The ultimate tool
for flameless
heating



2013:
*good industrial
design*

Winner GIO 2013
Special Award
ERGONOMICS

USER MANUAL

iDuctor[®] W1200

version: January 2014

Australian Distributor



Maintenance & Reliability Equipment

e: info@mrequip.com.au m: +61 417 954 430 w: mrequip.com.au



IDTOOLS.EU

Manufacturer

iDtools B.V.
Elektronicaweg 15
NL-2628 XG DELFT

H O L L A N D

www.idtools.eu
info@idtools.eu

T +31 (0) 88 06 06 500

F +31 (0) 88 06 06 555



Content

Items supplied	4
Product specifications	5
Power supply	5
Working environment	5
Instructions	5
Pictograms	5
Users	6
Instructions for use	6
LED lighting and fan	9
Rotary switch and push button	9
Error messages	10
Overheating protection	10
Connection safety feature	10
Mains current protection	10
Voltage and current protection	10
Maintenance	10
CE declaration	11
Patents and registration	12
Accessories	13
Set of coils	13
Accessory iDpad 1515	13
Guarantee and repairs	14



Introduction

The iDuctor uses the phenomenon of induction to heat magnetisable metal components such as nuts. Whether a particular material can be heated can be determined by experimentation. A set of eight different induction spirals and a flexible induction coil are supplied to allow heating of a wide range of components.

Read this user manual first before you use the iDuctor!

Items supplied

The iDuctor is supplied as a complete set in a robust box with the following contents:

- iDuctor
- set of three induction coils
- a mains cable with IEC Lock
- user manual
- safety data sheet



Product specifications

Power supply

- voltage: 230VAC +/- 10%
- frequency: 50 – 60 Hz
- output: 1200W
- the use of a generator is permissible if it is able to deliver adequate power and the output delivers clean sinus form voltage in the correct frequency range (50 – 60 Hz).
- safety class: Class I

WARNING

The unit must always be connected to a supply network with a fuse rated at at least 10A and at most 16A. The unit does not have an internal fuse.

An earth bonded wall socket should always be used on safety grounds (Class I).

WARNING

The unit does not feature an on/off switch, as soon as the plug is inserted in the socket the unit will be powered up.

Working environment

- temperature: -5°C to +40°C
- humidity: 0 – 90%, non-condensing
- IP 20
- no higher than 2,000 metres above sea level

Instructions

Pictograms

The pictograms appearing on the iDuctor have the following meanings:



Caution! This equipment generates a magnetic field which can erase magnetic data from credit cards and the like.



Caution!
Not to be used by persons with a pacemaker.



Caution!
This equipment includes components which may reach high temperatures.

Users

⚠ CAUTION

The iDuctor must not be used by persons in the following groups:

- users with a pacemaker;
- users with psychiatric or physical impairments whose use of the equipment would present a hazard to the user or their environment;
- users below 16 years of age without the supervision of an adult.

Instructions for use

The following must be checked before the equipment is connected to the mains supply:

- the original mains lead with its IEC Lock is connected
(in case of doubt, contact the supplier)
- the iDuctor is undamaged (no cracks or holes in the housing);
- only original iDuctor coils are used, manufactured in accordance
- with the manufacturer's specifications.






A coil or flexible coil must be connected to the unit. This connection is extremely robust thanks to the patented clamping mechanism. Coils and flexible coils are connected or removed by simultaneously depressing both buttons on the side of the unit. It is also possible to lie the unit down flat so that both buttons can be depressed with a single motion. An alternative method is to place the unit between the legs and depress the buttons with the knees, keeping both hands free.

The coil's contact points are then fully inserted in the holes at the front of the iDuctor. The buttons should then be released. The patented clamping mechanism will ensure that the spiral is held very firmly in place. Before using the unit check that the contacts have been fully inserted and that the connection is tight.

⚠ CAUTION

Select a coil which will fit closely around the object to be heated without touching it. This allows the optimal transfer of magnetic energy so that the object heats up as fast as possible, as well as preventing the coil's protective sleeve from being damaged by contact or wearing faster due to overheating.

**⚠ CAUTION**

When using the flexible induction coil it is important to wind as few turns around the object as possible. Where excessive turns are wound the current amperage will rise too high and the safety cut-out will trip. The optimal number of turns will vary between objects. Start with a single turn and gradually increase the number of turns as necessary.

⚠ CAUTION

If the iDuctor is used in one of the lower power settings it may produce a ticking sound: this is normal and not a fault.



Rotary switch and push button

The patented rotary switch at the rear of the iDuctor is used to adjust the heating time and power. These adjustments should be made before you press the push button on top of the unit to activate heating. The settings can not be adjusted during heating. Once adjustment is complete the coil is held around the object to be heated and the button on top of the unit is depressed. In positions 1 to 5 the unit will switch off automatically after the specified time. In position 6 the unit will continue to heat until the button is released or the iDuctor is switched off by the internal temperature safety cut-out. Once the iDuctor has cooled sufficiently the heating process will start up again automatically when you press the button. The iDuctor is active when the LED on the front is illuminated.

LED lighting and fan

The LED on the front of the unit will light up to illuminate the object when you press the button. The fan will then run to cool the system. The fan will remain active throughout the heating process and also thereafter if the measured internal temperature is high. Once the temperature has returned to a normal level the fan will switch off automatically. For this reason the 230 Volt mains connection should be maintained until the fan stops running. The iDuctor will switch off (or fail to switch on) if a fault is detected. In that case the LED light will flash when the button is depressed. (See: "Error messages".)



In order to prevent damage the iDuctor and the coil must be allowed to cool thoroughly after use before they are returned to their storage box. Both the unit and the coils can become hot in use.

Error messages

The iDuctor has a number of (patented) internal safety features. If one of these trips the unit will switch off and the LED will flash when the on/off button is depressed. The iDuctor is equipped with a patented microprocessor induction generator. In the event of overloading or overheating of the generator the processor automatically reduces the power to prevent damage to the induction generator.

Overheating protection

The unit will stop heating whenever its internal temperature rises too high.

Check:

- 1) that the fan is still operating
- 2) that the ventilation holes are unblocked
- 3) that power is connected, to ensure cooling
- 4) that only coils approved by the manufacturer are being used.

Solution: Delay heating until the unit has cooled sufficiently. The unit monitors the temperature itself, and it will not be usable until the internal temperature has fallen sufficiently. This will be detectable as you will hear the fan switch off.

Connection safety feature

Check:

- 1) that the coil is correctly connected
- 2) that the coils are not damaged
- 3) that the coils are not causing a short-circuit to earth or between the coils

Mains current protection

Check: If a generator is being used, check whether the iDuctor operates correctly when connected to the mains. It is possible that the power, voltage or frequency provided by the generator is not correct.

Voltage and current protection

Check:

- 1) that the mains voltage is not too high
- 2) that the coil is not causing a short-circuit to earth, or internally
- 3) where the flexible coil is being used, that not too many turns have been wound around the object to be heated.

Solution: Remove some turns from the object to be heated and retry.

Maintenance

The iDuctor is maintenance-free. The housing can be cleaned with a dry cloth.



Do not use a wet cloth or solvents: these can damage the unit or its operation.

Do not use an induction coil if the insulating protective sleeve is damaged or worn.

HedoN Electronic Developments B.V.
Delftech Park
Elektronicaweg 15
2628 XG DELFT
THE NETHERLANDS
Phone: +31 15 2755555
E-mail: info@hedon.nl
info@hedon.nl



Certificate of conformity

We,

HedoN electronic developments B.V.

declare, under our sole responsibility, that the product:

iDuctor with reference number HED7313001 till HED7313010

to which this declaration relates, is in conformity with EMC Directive (EMC) 2004/108/EC relating to electromagnetic compatibility and where appropriate is in conformity with the relevant following standard(s) or other such specifications:

EN 55011: (2009) + A1 (2010) (conducted and radiated emission)
EN 61000-6-1 (2007) Immunity
EN 61000-3-2 (2006) + A1 (2009) + A2 (2009) Emission
EN 61000-3-3 (2008) Emission

And also to the Low Voltage Directive 2006/95EC relating to safety and where appropriate is in conformity with the relevant following standard(s) or other such specifications:

EN 60335-1: (2012) Safety of household and similar electrical appliances

according to the technical specification of 24-6-2013 iDuctor kit version 02.

Place of issue : Delft
Date of issue : June 24, 2013

D.E.H. Lamaker
Manager Development



HedoN
Elektronicaweg 15, 2628 XG DELFT
Telefoonnummer: 015-275.5555
Faxnummer: 015-275.5550


www.hedon.nl

Patents and registration

All patented items are registered under number: EP 131665946.2



Unique clamping mechanism to allow easy exchange of coils and maintenance of a robust connection



Microprocessor controlled induction cycle



Single-control settings for operating power and switch-off time



Unique application of IEC Lock plug with electrical hand tool

Accessories



Set of coils

	article number	conductor thickness	internal diameter	winding	length	temperature-insulation
#						
1	52M30-240	3,5	52	3,5	240	250° C
1	47M24-240	3,5	47	3,5	240	250° C
1	40M20-200	3,5	40	3,5	200	250° C
1	32M16-200	3,5	32	3,5	200	250° C
1	32M12-200	3,5	26	3,5	200	250° C
1	32M10-250	3,5	23	3,5	250	250° C
1	32M10-150	3,5	23	3,5	150	250° C
1	18M08-150	3,5	18	3,5	150	250° C
1	Ucoil	3,5	160	0,5	600	250° C
1	FL1100	3,5		-	1100	450° C



Accessory iDpad 1515

For removing striping, bumpers, stickers, glue and paint residue etc.

Guarantee and repairs

iDtools B.V. and their sales agents offer a 1 year guarantee on all iDuctor 1200W components and materials from the date of purchase. The induction coils and the flexible induction coil are excluded from this guarantee. Users are assumed to have read through the user manual and safety instructions and to have acted accordingly.

This guarantee is not transferable. To make a claim you must present a sales receipt bearing the name of the owner of the iDuctor. This guarantee covers only the costs of components and labour used in repairing or replacing the iDuctor. Any other resultant costs do not fall within the provisions of the guarantee and are not covered.

The guarantee will lapse in the event of misuse, negligence, improper use, normal wear, modification or other unauthorised actions. The guarantee will also lapse if the iDuctor is improperly opened by a third party not authorised in writing to do so by iDtools.

iDtools shall not be liable in any circumstances for direct, indirect or contingent damage arising from the incorrect operation of an iDuctor.

The guarantee card must be completed in full and returned to the manufacturer within 30 days of purchase.

The card may also be scanned and sent by email to: info@idtools.co.uk. The guarantee can also be activated at the iDtools website, www.idtools.eu.

The cost of sending the item to the local sales agent, distributor or reseller will be borne by the end user. The costs of returning the item to the user will be borne by the local sales agent, distributor or reseller. The same principles will apply when the unit is returned to the manufacturer. iDtools B.V. shall in no circumstances be liable for transport, damage, theft or loss of the iDuctor.

Before returning a defective item you must first contact the local sales agent, distributor or reseller.

You can find further information on this at
<http://www.idtools.eu/service-en/guaranty-and-returns/>

Australian Distributor



Maintenance & Reliability Equipment

e: info@mrequip.com.au m: +61 417 954 430 w: mrequip.com.au



IDTOOLS.EU

Manufacturer

iDtools B.V.
Elektronicaweg 15
NL-2628 XG DELFT

H O L L A N D

www.idtools.eu
info@idtools.eu

T +31 (0) 88 06 06 500
F +31 (0) 88 06 06 555